







QD Bushings Taper Bushings Weld-On Hubs Bolt-On Hubs/Adapters



SECTION B

INTERCHANGEABLE BUSHINGS





QD BUSHINGS



QD ADAPTERS



TAPER BUSHINGS



TAPER BUSHED ADAPTERS

Warning & Safety Reminder



WARNING & SAFETY REMINDER

Safety must be considered a basic factor in machinery operation at all times. Most accidents are the result of carelessness or negligence. All rotating power transmission products are potentially dangerous and must be guarded by the contractor, installer, purchaser, owner, and user as required by applicable laws, regulations, standards, and good safety practice. Additional specific information must be obtained from other sources including the latest editions of American Society of Mechanical Engineers; Standard A.N.S.I. B15.1. A copy of this standard may be obtained from the American Society of Mechanical Engineers at 345 East 47th Street, New York, NY 10017 (212-705-7722).

It is the responsibility of the contractor, installer, purchaser, owner, and user to install, maintain, and operate the parts or components manufactured and supplied by *Martin* Sprocket & Gear, Inc., in such a manner as to comply with the Williams-Steiger Occupational Safety Act and with all state and local laws, ordinances, regulations, and the American National Standard Institute Safety Code.

CAUTION

Guards, access doors, and covers must be securely fastened before operating any equipment.

If parts are to be inspected, cleaned, observed, or general maintenance performed, **the motor driving the part or components is to be locked out electrically in such a manner that it cannot be started by anyone,** however remote from the area. Failure to follow these instructions may result in personal injury or property damage.

WARNING

NOTE: CATALOGUE DIMENSIONS

Every effort is made to keep all catalogue dimensions and styles current in the catalogue, however from time to time, it is necessary because of manufacturing changes to alter stock products dimensionally.

If any stock product dimension or style shown in this catalogue is critical to your application please consult factory for certification.





INTERCHANGEABLE BUSHINGS

PT0	DUCT	PAGE
IND	EX	B-1
BUS	SHING TYPES	B-2, B-3
QD		
	Installation/Removal	B-4, B-5
	Bushing Dimensions	B-6, B-7
	Standard Bushing	B-7
	Weld-On Hubs	B-8
TAP	ER BUSHING	
	1008-3030 Dimensions	B-9
	1008-3030 Available Bore Sizes	B-10
	3535-5050 Dimensions	B-11, B-12
	3535-5050 Available Bore Sizes	B-13
	6050-120100 Dimensions	B-14
	Installation/Removal	B-15
	Reborable Bushings	B-16
	Weld-On Hubs	B-17
	Bolt-On Hubs/Adapters	B-18



Monton'S QD BUSHING LINE NOT ONLY INCLUDES A COMPLETE RANGE OF SEMI-STEEL FROM JA-S BUT ALSO STEEL IN SIZES SF-N



WELD-ON ADAPTORS







Martin HAS THE MOST COMPLETE LINE OF TAPER BUSHINGS IN THE INDUSTRY, INCLUDING SEMI-STEEL, STEEL, AND STAINLESS STEEL



Stock "QD" Bushings



The *Mattin* "Quick Detachable" bushings are easy to install and remove. They are split through flange and taper to provide a true clamp on the shaft that is the equivalent of a shrink fit. All sizes except JA and H have a set screw over the key to help maintain the bushings position on the shaft until the cap screws are securely tightened.


Removal

- 1. Loosen and remove cap screws.
- 2. Insert cap screws in tapped removal holes.
- 3. Tighten inserted screws until sprocket is loose on shaft.
- 4. Remove sprocket from shaft.

Installation

- 1. Be sure the tapered cone surfaces of the bushing and the inside of sprocket are clean. ★
- Place bushing in sprocket, sheave, pulley, or other *Montin* QD parts. On M through S bushings, the mating part and bushing MUST be assembled so the two threaded holes in the mating part are located as far as possible from the sawcut in the bushing.
- 3. Place cap screws and lock washers loosely in pullup holes. Bushing remains fully expanded to assure sliding fit on shaft.
- With key on shaft, slide sprocket to desired position on shaft. Be Sure heads of capscrews are on outside.
- 5. Align sprocket. Tighten screws alternately and pro gressively until they are pulled up tight. To increase leverage, use wrench or length of pipe (see wrench torque chart on page B-5). Do not allow sprocket to be drawn in contact with flange of bushing; there should be a gap of 3.2 to 6.4 mm.

CAUTION: When mounting screws, apply pressure by hand only. If extreme tightening forces are applied, bursting pressures will be created in the sprocket hub. There should be a gap of 3.2 to 6.4mm between the face of the sprocket hub and the flange of the QD bushing. **This gap must not be closed.** If the gap is closed under normal tightening, the shaft is seriously undersized.



* WARNING: USE OF ANTI-SEIZE LUBRICANT ONTAPERED CONE SURFACES MAY RESULT IN DAMAGE TO SHEAVES AND SPROCKETS.





REVERSE Mounting Assembly for QD Sheaves and Sprockets using JA, SH, SD, SDS, SK, SF, E, F, & J Bushings

These bushings, as well as the sprockets and sheaves for them, are each drilled with six holes (three drilled and three tapped) to allow pull-up bolts to be inserted from either side. This enables variations of mounting characteristics to suit a particular installation.



REVERSE MOUNTING






MOUNTING


1. Assemble sheave or sprocket with bolts inserted (But not tightened) through DRILLED holes in bushing flange into TAPPED holes in sheave or sprocket.

2. With key in shaft keyseat, slide assembly into approximate position on shaft with flange end of bushing away from bearing.

3. Position QD bushing on shaft by tightening set screw over key "hand tight" with standard Allen wrench only. Do not use excessive force.



4. Tighten pull-up bolts alternately and evenly to indicated in torque table below. Do not use extensions on wrench handles. There should be a gap between the face of the sheave or sprocket hub and the flange of the QD Bushing to insure a satisfactory cone grip and press fit. CAUTION: THIS GAP MUST NOT BE CLOSED.



TAPERED CONE GRI

KEY SET SCREW


PULL UP BOLT

DISMOUNTING

1. Remove pull-up bolts and screw them into TAPPED holes in bushing flange and against hub of sheave or sprocket to break cone grip.

2. Loosen set screw in bushing flange and slide QD bushing from shaft.

Bushing Installation Torque



When a wrench or length of pipe is used to increase leverage in tightening bushing screws, it is imperative to adhere to the wrench torgue values given in the chart below.

This adherence is important — because, in mounting the bushing, the tightening force of the screw is multiplied many times by the wedging action of the tapered surface. This action compresses the bushing for a snug fit on the shaft. The bushing screws should always be tightened alternately and progressively.

Wrench Torque Values For Tightening Bushings

QD Bushing Size	Size of Cap	Force to apply with torque	Proper Wrench Pull With Open End or Socket Wrench	
	Screw (Inch)	wrench (Nm)	Wrench Length (mm)	Wrench Pull (kg)
JA	10-24	6.8	101.6	6.8
SH, SDS, SD	1/4-20	12.2	101.6	12.3
SK	5/16-18	20.3	152.4	13.6
SF	3/8-16	40.7	152.4	27.2
E	1/2-13	81.3	304.8	27.2
F	9/16-12	101.7	304.8	34.0
J	5/8-11	183.0	304.8	61.3
M	3/4-10	305.0	381.0	81.7
N	7/8-9	406.7	381.0	108.9
Р	1-8	610.1	457.2	136.1
W	1-1/8-7	813.5	609.6	136.1
S	1-1/4 -7	1016.8	762.0	136.1

CAUTION


- A. Be sure cone surfaces are free of paint, grease and dirt.
- B. Tighten pull-up bolts alternately and evenly per bolt torque table
- C. Never close gap between sheave or sprocket and QD Bushing.


WARNING: use of Anti-seize lubricant on tapered cone surfaces when mounting sheaves voids all mfg_warranties


See A. B. C on drawings.

All Steel "QD" Bushings









Bushings "M" to "S" Inclusive

QD Bushings — Steel

			Dimensior	ıs (inches)				Sto	ck Bore Rai	nge	Average
Bushing						Cap	Screws		Maxi	mum	Weight
	A	В	D	E	L	Bolt Circle	Required	Minimum	Standard Keyway	Shallow Keyway	Approx. (Kg)
SF-STL	⁹ / ₁₆	3.125	4 ⁵ / ₈	1.438	2	3 ⁷ /8	(3) ³ / ₈ × 2	1/2	2 ⁵ / ₁₆	2 ¹³ / ₁₆	3.0
E-STL	³ / ₄	3.843	6	1 ⁷ /8	2 ⁵ /8	5	(3) $\frac{1}{2} \times 2^{3}/_{4}$	7/ ₈	2 ⁷ / ₈	3 ¹ / ₂	10.0
F-STL	¹⁴ / ₁₆	4.437	6 ⁵ / ₈	2 ³ / ₄	3 ⁵ / ₈	5 ⁵ /8	(3) ⁹ / ₁₆ × 3 ⁵ / ₈	1	3 ⁵ / ₁₆	4	11.5
J-STL	1	5.148	7 ⁶ /25	3 ¹ / ₂	4 ¹ / ₂	6 ¹ / ₄	(3) ⁵ / ₈ × 4 ¹ / ₂	1 ⁷ / ₁₆	3 ³ / ₄	4 ¹ / ₂	18.0
M-STL	1 ¹ / ₄	6.500	9	5 ¹ / ₂	6 ³ / ₄	7 ⁷ /8	(4) ³ / ₄ × 6 ³ / ₄	2	4 ³ / ₄	5 ¹ / ₂	37.0
N-STL	1 ¹ / ₂	7.000	10	6 ⁵ /8	8 ¹ / ₈	8 ¹ / ₂	(4) ⁷ / ₈ × 8 ¹ / ₂	2 ¹ / ₂	5 ¹ / ₈	5 ⁷ /8	57.0

Bushing	Bores	Keyway
SF-STL	2 ³ / ₈ - 2 ⁹ / ₁₆ 2 ⁵ / ₈ - 2 ³ / ₄ 2 ¹³ / ₁₆ - 2 ⁷ / ₈ 2 ¹⁵ / ₁₆	$5/8 \times 3/16$ $5/8 \times 1/16$ $3/4 \times 1/16$ $3/4 \times 1/32$
E-STL	⁷ / ₈ - 2 ⁷ / ₈ 2 ¹⁵ / ₁₆ - 3 ¹ / ₄ 3 ⁵ / ₁₆ - 3 ¹ / ₂	STD. ³ / ₄ × ¹ / ₈ ⁷ / ₈ × ¹ / ₁₆
F-STL	1 - 3 ⁵ / ₁₆ 3 ³ / ₈ - 3 ³ / ₄ 3 ⁷ / ₈ - 3 ¹⁵ / ₁₆ 4	STD. ⁷ / ₈ × ³ / ₁₆ 1 × ¹ / ₈ NONE
J-STL	3 ⁷ / ₁₆ - 3 ³ / ₄ 3 ¹³ / ₁₆ - 4 ¹ / ₂	STD. 1 × ¹ /8
M-STL	2 - 4 ³ / ₄ 4 ¹³ / ₁₆ - 5 ¹ / ₂ 5 ⁹ / ₁₆ - 5 ⁷ / ₈	STD. 1 ¹ / ₄ × ¹ / ₄ 1 ¹ / ₂ × ¹ / ₄
N-STL	2 ¹ / ₂ - 5 ¹ / ₈ 5 ³ / ₁₆ - 5 ¹ / ₂ 5 ⁹ / ₁₆ - 5 ⁷ / ₈	STD. 1 ¹ / ₄ × ¹ / ₄ 1 ¹ / ₂ × ¹ / ₄

Plain Bores Not Split

 $^{1}/_{2}$

 $^{1}/_{2}$

¹/₂ **1** ¹⁵/₁₆

⁷/8 - 1 ¹⁵/₁₆

1 - 2 ⁷/₁₆ - 2 ¹⁵/₁₆

1 ⁷/₁₆ - 2 ¹⁵/₁₆ 2 - 2 ¹⁵/₁₆

2 ⁷/₁₆ - 4 ¹⁵/₁₆

Imperial Shallow Key Dimension - Standard							
Key Seat	Key	Keyway	Key				
¹ / ₄ × ¹ / ₃₂	$^{1}/_{4} \times ^{5}/_{32}$	$^{3}/_{4} \times ^{1}/_{8}$	$^{3}/_{4} \times ^{1}/_{2}$				
$^{1}/_{4} \times ^{1}/_{16}$	$^{1}/_{4} \times ^{3}/_{16}$	$^{7}/_{8} \times ^{1}/_{16}$	$^{7}/_{8} \times ^{1}/_{2}$				
$^{3}/_{8} \times ^{1}/_{32}$	$^{3}/_{8} \times ^{7}/_{32}$	⁷ / ₈ × ³ / ₁₆	$^{7}/_{8} \times ^{5}/_{8}$				
$^{3}/_{8} \times ^{1}/_{16}$	$^{3}/_{8} \times ^{1}/_{4}$	1 × ¹ / ₈	1 × ⁵ / ₈				
$^{3}/_{8} \times ^{1}/_{8}$	$^{3}/_{8} \times ^{5}/_{16}$	1 ¹ / ₄ × ¹ / ₄	1 ¹ / ₄ × ⁷ / ₈				
$^{1}/_{2} \times ^{1}/_{32}$	$^{1}/_{2} \times ^{9}/_{32}$	1 ¹ / ₂ × ¹ / ₈	1 ¹ / ₂ × ⁷ / ₈				
$^{1}/_{2} \times ^{1}/_{16}$	$^{1}/_{2} \times ^{5}/_{16}$	1 ¹ / ₂ × ¹ / ₄	1 ¹ / ₂ × 1				
$1/_2 \times 1/_8$	$^{1}/_{2} \times ^{3}/_{8}$	1 ³ / ₄ × ¹ / ₈	1 ³ / ₄ × ³ / ₄				
$\frac{5}{8} \times \frac{1}{16}$	⁵ / ₈ × ³ / ₈	1 ³ / ₄ × ¹ / ₄	1 ³ / ₄ × ⁷ / ₈				
$^{3}/_{4} \times ^{1}/_{16}$	$^{3}/_{4} \times ^{7}/_{16}$	2 × 1/4	2 × 1				

Imperia	Imperial Shallow Key Dimension - Steel						
Key Seat	Key	Keyway	Key				
$^{1}/_{4} \times ^{1}/_{32}$	$^{1}/_{4} \times ^{5}/_{32}$	$^{3}/_{4} \times ^{1}/_{16}$	$^{3}/_{4} \times ^{7}/_{16}$				
$^{1}/_{4} \times ^{1}/_{16}$	$^{1}/_{4} \times ^{3}/_{16}$	$^{3}/_{4} \times ^{1}/_{8}$	$^{3}/_{4} \times ^{1}/_{2}$				
$^{3}/_{8} \times ^{1}/_{32}$	$^{3}/_{8} \times ^{7}/_{32}$	⁷ / ₈ × ¹ / ₁₆	$^{7}/_{8} \times ^{1}/_{2}$				
$^{3}/_{8} \times ^{1}/_{16}$	$^{3}/_{8} \times ^{1}/_{4}$	$^{7}/_{8} \times ^{3}/_{16}$	$^{7}/_{8} \times ^{5}/_{8}$				
$^{3}/_{8} \times ^{1}/_{8}$	$^{3}/_{8} \times ^{5}/_{16}$	1 × ¹ /8	1 × ⁵ /8				
$1/_2 \times 1/_{32}$	$^{1}/_{2} \times ^{3}/_{32}$	1 ¹ / ₄ × ¹ / ₄	1 ¹ / ₄ × ⁷ / ₈				
$1/_2 \times 1/_{16}$	$^{1}/_{2} \times ^{5}/_{16}$	1 ¹ / ₂ × ¹ / ₄	1 ¹ / ₂ × 1				
$^{1}/_{2} \times ^{1}/_{8}$	$^{1}/_{2} \times ^{3}/_{8}$	1 ³ / ₄ × ¹ / ₈	1 ³ / ₄ × ³ / ₄				
$\frac{5}{8} \times \frac{1}{16}$	⁵ / ₈ × ³ / ₈	1 ³ / ₄ × ³ / ₈	1 ³ / ₄ × 1				
$^{5}/_{8} \times ^{3}/_{16}$	$\frac{5}{8} \times \frac{1}{2}$	2 × 1/4	2 × 1				

Standard I	Standard Imprial Keyway and Key Dimension						
Bores	Keyway Key						
7/8	$^{3}/_{16} \times ^{3}/_{32}$	³ / ₁₆ × ³ / ₁₆					
¹⁵ / ₁₆ - 1 ¹ / ₄	$^{1}/_{4} \times ^{1}/_{8}$	$^{1}/_{4} \times ^{1}/_{4}$					
1 ⁵ / ₁₆ - 1 ³ / ₈	$^{5}/_{16} \times ^{5}/_{32}$	$^{5}/_{16} \times ^{5}/_{16}$					
1 ⁷ / ₁₆ - 1 ³ / ₄	$^{3}/_{8} \times ^{3}/_{16}$	$3/_8 \times 3/_8$					
1 ³ / ₁₆ - 2 ¹ / ₄	$1/_2 \times 1/_4$	$1/_2 \times 1/_2$					
2 ⁵ / ₁₆ - 2 ³ / ₄	⁵ / ₈ × ⁵ / ₁₆	⁵ / ₈ × ⁵ / ₈					
2 ¹³ / ₁₆ - 3 ¹ / ₄	$^{3}/_{4} \times ^{3}/_{8}$	$^{3}/_{4} \times ^{3}/_{4}$					
3 ⁵ / ₁₆ - 3 ³ / ₄	$^{7}/_{8} \times ^{7}/_{16}$	$^{7}/_{8} \times ^{7}/_{8}$					
3 ¹³ / ₁₆ - 4 ¹ / ₂	1 × 1/2	1×1					
4 ⁹ / ₁₆ - 5 ¹ / ₂	1 ¹ / ₄ × ⁵ / ₈	1 ¹ / ₄ × 1 ¹ / ₄					
5 ⁹ / ₁₆ - 6 ¹ / ₂	1 ¹ / ₂ × ³ / ₄	1 ¹ / ₂ × 1 ¹ / ₂					
6 ⁹ / ₁₆ - 7 ¹ / ₂	1 ³ / ₄ × ³ / ₄	1 ³ / ₄ × 1 ¹ / ₂					
7 ⁹ / ₁₆ - 9	2 × ³ / ₄	2 1/2 × 1 1/2					
9 ¹ / ₁₆ - 11	2 ¹ / ₂ × ⁷ / ₈	—					
11 ¹ / ₁₆ - 13	3 × 1	—					

QD bushings made of stainless steel are available as made to order.

Bushing

SH-STL

SD-STL

SK-STL

SF-STL

E-STL

F-STL J-STL

M-STL

N-STL




Standard "QD" Bushings

			Dimensio	ons (Inch)				Stock	Bore Range	e (mm)		Average
Bushing						Bolt	Cap Screws		Maxi	mum	Set Screw	Weight
J	A	В	D	E	L	Circle	Required	Minimum	Standard Keyway	Shallow Keyway	Size (In)	Approx. (Kg)
Н	6.35	41.3	63.5	25.4	31.8	50.8	$2^{-1}/_4 \times {}^3/_4$	12.7	31.8	38.1	1/4	0.32
JA	8.0	34.9	50.8	17.4	25.4	42.16	3-10 × 1	9.5	25.4	31.8	10-24	0.41
SH	11.1	47.5	68.0	22.6	31.8	57.2	3-1/4 × 1 3/8	12.7	34.9	42.9	1/4	0.45
SDS	11.1	55.6	80.7	22.3	33.4	68.3	3-1/4 × 1 3/8	12.7	42.9	50.8	1/4	0.45
SD	11.1	55.6	80.7	35.0	46.1	68.3	3-1/4 × 1 7/8	12.7	42.9	49.2	1/4	0.68
SK	14.3	71.4	98.2	33.3	47.6	84.1	3-5/16 × 2	12.7	54.0	63.5	⁵ / ₁₆	0.91
SF	14.3	79.4	117.2	36.5	50.8	98.4	$3^{-3}/_{8} \times 2$	12.7	58.7	71.4	⁵ / ₁₆	1.36
E	19.1	97.4	152.0	47.6	66.7	127.0	$3^{-1}/_2 \times 2^{-3}/_4$	22.2	73.0	88.9	³ /8	4.54
F	22.23	112.7	168.0	69.85	92.1	142.9	3-9/16 × 3 5/8	25.4	84.1	100.0	1/ ₂	5.22
J	25.4	130.8	183.0	88.9	114.3	158.8	3-5/8 × 4 1/2	31.75	95.3	114.3	⁵ / ₈	8.17
М	31.8	165.1	228.4	139.7	171.5	200.0	4-3/4 × 6 3/4	50.81	120.7	139.7	3/4	16.79
N	38.1	177.8	253.8	168.3	206.4	215.9	4-7/8 × 8 1/2	61.9	130.2	152.4	3/4	25.86
Р	44.5	209.6	298.2	193.7	238.1	254.0	4-1 × 9 ¹ / ₂	74.6	150.8	177.8	7/ ₈	54.45
W	50.8	265.1	380.8	238.1	288.9	323.9	4-1 ¹ / ₈ × 11 ¹ / ₂	101.6	190.5	215.9	1	113.43
S	82.6	308.0	450.9	317.5	400.1	381.0	5-1 ¹ / ₄ × 15 ¹ / ₂	152.4	206.8	254.0	1	181.49

Inch Bore

Bushing	Bores	Keyway
JA	$3/_8 - 7/_{16} 1/_2 - 1 1 1/_{18} - 1 1/_8 1 3/_{16} 1 1/_4$	NO K.W. STD. ¹ / ₄ - ¹ / ₁₆ ¹ / ₄ - ¹ /1 ₆ NO K.W.
SH	$\frac{1}{2} - 1 \frac{3}{8}$ 1 $\frac{7}{16} - 1 \frac{1}{2}$ 1 $\frac{9}{16} - 1 \frac{5}{8}$ 1 $\frac{11}{16}$	STD. ³ / ₈ × ¹ / ₁₆ ³ / ₈ × ¹ / ₁₆ NO K.W.
SDS	${}^{1/_{2}} - 1 {}^{11/_{16}} \\ 1 {}^{3/_{4}} \\ 1 {}^{13/_{16}} \\ 1 {}^{7/_{8}} - 1 {}^{15/_{16}} \\ 2$	STD. ³ / ₈ × ¹ / ₈ ¹ / ₂ × ¹ / ₈ ¹ / ₂ × ¹ / ₁₆ NO K.W.
SD	${}^{1/_{2} - 1}_{10} {}^{11/_{16}}_{13/_{4}}_{113/_{16}}_{17/_{8}}_{115/_{16}}_{15/_{16}}_{2}$	STD. $3/_8 \times 1/_8$ $1/_2 \times 1/_8$ $1/_2 \times 1/_{16}$ $1/_2 \times 1/_{16}$ NO K.W.
SK	¹ / ₂ - 2 ¹ / ₈ 2 ³ / ₁₆ - 2 ¹ / ₄ 2 ⁵ / ₁₆ - 2 ¹ / ₂ 2 ⁹ / ₁₆ - 2 ⁵ / ₈	STD. ¹ / ₂ × ¹ / ₈ ⁵ / ₈ × ¹ / ₁₆ NO K.W.
SF	$\frac{\frac{1}{2} - 2 \frac{1}{4}}{2 \frac{5}{16} - 2 \frac{1}{2}}$ $\frac{\frac{9}{16} - 2 \frac{3}{4}}{2 \frac{13}{16} - 2 \frac{7}{8}}$ $\frac{2 \frac{15}{16}}{2 \frac{15}{16}}$	STD. $5/_8 \times 3/_{16}$ $5/_8 \times 1/_{16}$ $3/_4 \times 1/_{16}$ $3/_4 \times 1/_{32}$
E	⁷ / ₈ - 2 ⁷ / ₈ 2 ¹⁵ / ₁₆ - 3 ¹ / ₄ 3 ³ / ₈ - 3 ¹ / ₂	STD. ³ / ₄ × ¹ / ₈ ⁷ / ₈ × ¹ / ₁₆
F	1 - 3 ⁵ / ₁₆ 3 ³ / ₈ - 3 ³ / ₄ 3 ⁷ / ₈ - 3 ¹⁵ / ₁₆ 4	STD. ⁷ / ₈ × ³ / ₁₆ 1 × ¹ / ₈ NONE
J	1 ¹ / ₄ - 3 ³ / ₄ 3 ¹³ / ₁₆ - 4 ¹ / ₂	STD. 1 × ¹ /8
М	2-4 ³ / ₄ 4 ¹³ / ₁₆ - 5 ¹ / ₂	STD. 1 ¹ / ₄ × ¹ / ₄
N	2 ⁷ / ₁₆ - 5 5 ¹ / ₈ - 5 ¹ / ₂ 5 ⁹ / ₁₆ - 6	STD. 1 ¹ / ₄ × ¹ / ₄ 1 ¹ / ₂ × ¹ / ₄
Р	2 ¹⁵ / ₁₆ - 5 ¹⁵ / ₁₆ 6 - 6 ¹ / ₂ 6 ⁹ / ₁₆ - 7	STD. 1 ¹ / ₂ × ¹ / ₄ 1 ³ / ₄ × ¹ / ₈
W	4 - 7 ¹ / ₂ 7 ⁹ / ₁₆ - 8 ¹ / ₂	STD. 2 × ¹ / ₄



★ Important —— The metric system does not refer to keyseat or keyway dimensions as does the English system; instead dimensions are given for the key itself which is rectangular in shape, not square as in the English system.

NOTE:	TO ORDER
.03937"=1mm	SH 24mm
EX-24mm=0.94488"	

Millimeter Bore

Bushing	Bores MM	Keyway* WXT
SH	24.25 28.30	8×7
ЗП	32.35	10×8
	24.25 28.30	8×7
SDS	32.35	10×8
	38 40.42	10×0 12×8
	24.25	8×7
SD	28.30	0×1
5D	32.35 38	10×8
	40.42	12×8
	24.25 28.30	8×7
	32.35	10×8
SK	38 40.42	12×8
	48.50	14×9
	55	16×10
	28.30 32.35	8×7
05	38	10×8
SF	40.42 48.50	12×8 14×9
	55	16×10
	60 35.38	18×11 10×8
	40.42	12×8
Е	48.50 55	14×9 16×10
	60.65	18×11
	70.75 48.50	20×12 14×9
	55	16×10
F	60.65	18×11
	70.75 80.85	20×12 22×14
	90	25×14
	50 55	14×9 16×10
	60.65	18×11
J	70.75 80.85	20×12 22×14
	90.95	25×14
	100	28×16

Keystock provide for nonstandard keyways.


"QD" Weld-On Hubs





Martin QD weld-on hubs are suitable for use in many applications, such as welding to plate steel sprockets.

Weld-on hubs are made of steel, drill tapped and taper bored for QD bushings.




QD Type 1 and Type 2 Weld-On Hubs

Mountina	Approx.	Туре			ns - (MM)	Dimensio			Catalogue
woulding	Weight Kg	Drilling	BC	L1	Р	В	L	D*	Number
	.18	1	42.1	-	-	34.9	14.3	57.2	JA-A
STD or	.45	1	57.2	-	-	47.5	20.6	76.2	SH-A
Reverse Mount	.57	1	68.3	-	-	55.6	19.1	88.9	SDS-A
	1.36	1	84.1	-	-	71.5	31.8	111.1	SK-A
	1.81	1	98.4	-	-	79.4	31.8	127.0	SF-A
	4.08	1	127.0	-	-	97.3	41.3	158.8	E-A
	7.26	1	142.9	-	-	112.7	63.5	177.8	F-A
	10.21	1	158.8	-	-	130.6	81.0	196.9	J-A
	22.69	2	200.0	90.5	235.0	164.9	131.8	241.3	M-A
STD	34.03	2	215.9	114.3	260.4	177.5	158.8	266.7	N-A
Mount	70.33	2	254.0	-	-	209.3	184.2	330.2	P-A
Only	136.12	2	323.9	-	-	265.1	228.6	393.7	W-A
	253.18	3	381.0	190.5	476.3	308.0	304.8	495.3	S-A

★ Tolerance of D Dimension

JA-A Thru J-A = (+.000-.050) M-A Thru S-A = (+.000-.076)





Dimensions

				CØ				L	*	М	**
Bushing Number	A	В	Class 20 Gray Iron	Class 30 Gray Iron	Steel	D	F(†) (in)	Standard Hex. Key	Standard Short Key‡	Hex. Key	Short Key
1008	35.2	22.3	60.3	55.6	49.2	33.7	$^{1}/_{4} \times ^{1}/_{2}$	28.6	15.9	31.8	44.5
1108	38.4	22.3	63.5	58.7	52.4	36.9	$1/_4 \times 1/_2$	28.6	15.9	31.8	44.5
1210	47.6	25.4	92.1	82.6	73.0	44.4	$^{3}/_{8} \times ^{5}/_{8}$	34.9	20.6	41.3	27.0
1215	47.6	38.1	79.4	73.0	66.7	44.4	$^{3}/_{8} \times ^{5}/_{8}$	34.9	20.6	41.3	27.0
1310	50.8	25.4	95.3	85.7	76.2	47.6	$^{3}/_{8} \times ^{5}/_{8}$	34.9	20.6	41.3	27.0
1610	57.2	25.4	101.6	101.6	82.6	54.0	$^{3}/_{8} \times ^{5}/_{8}$	34.9	20.6	41.3	27.0
1615	57.2	38.1	88.9	82.6	76.2	54.0	$^{3}/_{8} \times ^{5}/_{8}$	34.9	20.6	41.3	27.0
2012	69.9	31.8	120.7	116.8	98.4	66.7	$^{7}/_{16} \times ^{7}/_{8}$	39.7	23.8	50.8	34.9
2517	85.7	44.5	139.7	123.8	111.1	82.6	¹ / ₂ × 1	41.3	25.4	57.2	41.3
2525	85.7	63.5	120.7	114.3	108.0	82.6	¹ / ₂ × 1	41.3	25.4	57.2	41.3
3020	108.0	50.8	177.8	158.8	142.9	101.6	⁵ / ₈ × 1 ¹ / ₄	46.0	30.2	68.3	52.4
3030	108.0	76.2	158.8	146.1	136.5	101.6	⁵ / ₈ × 1 ¹ / ₄	46.0	30.2	68.3	52.4

Bushings cannot be bored larger than largest bore listed. For detail dimensions required for machining hubs, consult factory.

Ø For general reference. Severe conditions may require larger hub. Heavy well-located web may permit smaller hub. Hub diameter required depends on the particular application. Consult *Mather* giving full information on the proposed design. Hub diameters shown are based on 1400, 2110 and 3500 Kg/Cm². Minimum ultimate tensile strength respectively for Class 20 gray iron, Class 30 gray iron and steel hubs.

† 2 screws required. Use in positions shown for tightening bushing on shaft. In removing bushing from shaft, remove screws and use one of them in the other hole. Bushing price includes screws. Screws are BSW threads.

- ★ Space required to tighten bushing. Also space required to loosen screws to permit removal of hub by puller.
- ★★ Space required to loosen bushing using one screw as jackscrew no puller required.
- \$ Standard hex key cut to minimum usable length.



Metric Bores and Keyways

Bore	Key	way	Shallow				Bore	Sizes Ava	lable			
Dia. (mm)	Width (mm)	Depth (mm)	Keyway Depth	1008	1108	1210	1610	1615	2012	2517	3020	3030
9	3	1.4	—	٠	•							
10	3	1.4	—	•	•							
11	4	1.8	—	•	•	•						
12	4	1.8	-	•	•	•						
14	5	2.3	—	•	•	•	•	•	•			
15	5	2.3	—	•	•	•	•	•	•			
16	5	2.3	-	•	•	•	•	•	•	•		
18	6	2.8	-	•	•	•	•	•	•	•		
19	6	2.8	_	•	•	•	•	•	•	•		
20	6	2.8	—	•	•	•	•	•	•	•		
22	6	2.8	—	•	•	•	•	•	•	•		
24	8	3.3	1.3	•	•	•	•	•	•	•		
25	8	3.3	1.3	•*	•	•	•	•	•	•	•	
28	8	3.3	1.3		•*	•	•	•	•	•	•	
30	8	3.3	—			•	•	•	•	•	•	
32	10	3.3	—			•	•	•	•	•	•	
35	10	3.3	—				•	•	•	•	•	•
38	10	3.3	_				•	•	•	•	•	•
40	12	3.3	—				•	•	•	•	•	•
42	12	3.3	2.2				•	•*	•	•	•	•
45	14	3.8	—						•	•	•	•
48	14	3.8	-						•	•	•	•
50	14	3.8	—						•	•	•	•
55	16	4.3	_							•	•	•
60	18	4.4	—							•	•	•
65	18	4.4	—								•	•
70	20	4.9	-								•	•
75	20	4.9	—								•	•


Items marked with""have a shallow keyway.

Inch Bore and Keyways

Bore	Key	way	Shallow				Bore	Sizes Avai	lable			
Dia. (In.)	Width (In.)	Depth (In.)	Keyway Depth	1008	1108	1210	1610	1615	2012	2517	3020	3030
0.375	0.125	0.06	-	•	•							
0.500	0.125	0.06	-	•	•		•	•				
0.625	0.187	0.09	-	•	•	•	•	•				
0.750	0.187	0.09	-	•	•	•	•	•	•	•		
0.875	0.250	0.12	-	•	•	•	•	•	•	•		
1.000	0.250	0.12	0.052	•*	•	•	•	•	•	•		
1.125	0.312	0.11	0.064		•*	•	•	•	•	•		
1.250	0.312	0.11	-			•	•	•	•	•	•	•
1.375	0.375	0.11	-				•	•	•	•	•	•
1.500	0.375	0.11	-				•	•	•	•	•	•
1.625	0.437	0.13	0.103				•	•*	•	•	•	•
1.750	0.437	0.13	-						•	•	•	•
1.875	0.500	0.13	-						•	•	•	•
2.000	0.500	0.13	-						•	•	•	•
2.125	0.625	0.18	-							•	•	•
2.250	0.625	0.18	-							•	•	•
2.375	0.625	0.18	-							•	•	•
2.500	0.625	0.18	-							•	•	•
2.625	0.750	0.21	-								•	•
2.750	0.750	0.21	-								•	•
2.875	0.750	0.21	-								•	•
3.000	0.750	0.21	-								•	•

Items marked with""have a shallow keyway.





No.3525 to 4040 Bushings

								CØ					
Bushing Number	Bore	Approx. Wgt. (Kg)	Bushing Keyseat	Shaft Keyseat	A	В	Class 20 Gray Iron	Class 30 Gray Iron	Steel	D	F† (in)	G	R
3525	30 to 38 38 to 44 44 to 50 50 to 58 58 to 65 65 to 75 75 to 85 85 to 95 95 to 110	4.5 4.2 4.1 3.6 3.2 2.7 2.2 2.1	10×3.3 12×3.3 14×3.8 16×4.3 18×4.4 20×4.9 22×5.4 25×5.4 28×4.5	$10 \times 5.0 \\ 12 \times 5.0 \\ 14 \times 5.5 \\ 16 \times 6.0 \\ 18 \times 7.0 \\ 20 \times 7.5 \\ 22 \times 9.0 \\ 25 \times 9.0 \\ 28 \times 10.0 \\ 10 \times 10 \times 10.0 \\ 10 \times 10$	127	63.5	197	178	165	123	¹ / ₂ × 1 ¹ / ₂	39°	
3535	30 to 38 38 to 44 44 to 50 50 to 58 58 to 65 65 to 75 75 to 85 85 to 95 95 to 110	6.4 6.2 5.9 5.4 5.0 4.5 4.0 3.6 3.2	10×3.3 12×3.3 14×3.8 16×4.3 18×4.4 20×4.9 22×5.4 25×5.4 28×4.5	$10 \times 5.0 \\ 12 \times 5.0 \\ 14 \times 5.5 \\ 16 \times 6.0 \\ 18 \times 7.0 \\ 20 \times 7.5 \\ 22 \times 9.0 \\ 25 \times 9.0 \\ 28 \times 10.0 \\ 12 \times 10.0 \\ 10 \times 10 \times 10.0 \\ 10 \times 10$	127	89	197	178	165	123	¹ / ₂ ×1 ¹ / ₂	39°	•
4030	38 to 44 44 to 50 50 to 58 58 to 65 65 to 75 75 to 85 85 to 95 95 to 110 111 to 115	7.7 7.3 6.8 6.4 5.9 5.4 5.0 4.8 4.5	12×3.3 14×3.8 16×4.3 18×4.4 20×4.9 22×5.4 25×5.4 28×6.4 32×5.5	12×5.0 14×5.5 16×6.0 18×7.0 20×7.5 22×9.0 25×9.0 28×10.0 32×11.0	146	76.2	241	216	197	141	⁵ /8 ×1 ³ /4	40°	
4040	38 to 44 44 to 50 50 to 58 58 to 65 65 to 75 75 to 85 85 to 95 95 to 110 111 to 115	10.0 9.5 9.0 8.6 8.2 7.7 6.8 6.4 5.9	12×3.3 14×3.8 16×4.3 18×4.4 20×4.9 22×5.4 25×5.4 28×4.4 32×4.4	12×5.0 14×5.5 16×6.0 18×7.0 20×7.5 22×9.0 25×9.0 28×10.0 32×11.0	146	102	241	216	197	141	⁵ / ₈ ×1 ³ / ₄	40°	•

Bushings cannot be bored larger than largest bore listed. For detail dimensions required for machining hubs, consult factory.


For general reference. Severe conditions may require larger hub. Heavy well-located web may permit smaller hub. Hub diameter required depends on the particular application. Consult factory giving full information on the proposed design. Hub diameters shown are based on 20,000, 30,000 and 50,000 P.S.I. minimum ultimate tensile strength respectively for Class 20 gray iron, Class 30 gray iron and steel hubs.

† 3 screws required. Use in positions shown for tightening bushing on shaft. In removing bushing from shaft, remove screws and use two of them in the other two holes. Bushing price includes screws. See following footnote.

Provide sufficient space to tighten and loosen bushing. Width across flats of screw head is same as screw diameter which is shown in column F.







No.4535 to 5050 Bushings

								CØ					
Bushing Number	Bore	Approx. Wgt.(Kg)	Bushing Keyseat	Shaft Keyseat	A	В	Class 20 Gray Iron	Class 30 Gray Iron	Steel	D	F† (in)	G	R
4535	50 to 58 58 to 65 65 to 75 75 to 85 85 to 95 95 to 110 110 to 120	10.4 10.0 9.5 9.1 8.2 7.3 6.4	$16 \times 4.3 \\ 18 \times 4.4 \\ 20 \times 4.9 \\ 22 \times 5.4 \\ 25 \times 5.4 \\ 28 \times 6.4 \\ 32 \times 7.4$	16×6.0 18×7.0 20×7.5 22×9.0 25×9.0 28×10.0 32×11.0	162	89	267	241	222	156	³ / ₄ "×2"	40°	
4545	50 to 58 58 to 65 65 to 75 75 to 85 85 to 95 95 to 110 110 to 120	13.6 12.7 12.2 11.8 10.4 9.1 8.2	$16 \times 4.3 \\ 18 \times 4.4 \\ 20 \times 4.9 \\ 22 \times 5.4 \\ 25 \times 5.4 \\ 28 \times 6.4 \\ 32 \times 7.4$	16×6.0 18×7.0 20×7.5 22×9.0 25×9.0 28×10.0 32×11.0	162	114	267	241	222	156	³ /4"×2"	40°	•
5040	65 to 75 75 to 85 85 to 95 95 to 110 110 to 130 130 to 140	13.1 12.7 11.8 10.9 10.0 8.9	$20 \times 4.9 \\ 22 \times 5.4 \\ 25 \times 5.4 \\ 28 \times 6.4 \\ 32 \times 7.4 \\ 36 \times 8.4$	20×7.5 22×9.0 25×9.0 28×10.0 32×11.0 36×12.0	178	101,6	292	267	241	171	⁷ /8"×2 ¹ /4"	37°	•
5050	65 to 75 75 to 85 85 to 95 95 to 110 110 to 130 130 to 140	17.2 15.9 14.5 12.2 10.9 10.4	$20 \times 4.9 22 \times 5.4 25 \times 5.4 28 \times 6.4 32 \times 7.4 36 \times 6.4$	20×7.5 22×9.0 25×9.0 28×10.0 32×11.0 36×12.0	178	127	292	267	241	171	⁷ /8"×2 ¹ /4"	37°	•

Bushings cannot be bored larger than largest bore listed.

For detail dimensions required for machining hubs, consult factory.

Ø For general reference. Severe conditions may require larger hub. Heavy well-located web may permit smaller hub. Hub diameter required depends on the particular application. Consult factory giving full information on the proposed design. Hub diameters shown are based on 20,000, 30,000 and 50,000 P.S.I. minimum ultimate tensile strength respectively for Class 20 gray iron, Class 30 gray iron and steel hubs.

† 3 screws required. Use in positions shown for tightening bushing on shaft. In removing bushing from shaft, remove screws and use two of them in the other two holes. Bushing price includes screws. See following footnote.

A Provide sufficient space to tighten and loosen bushing. Width across flats of screw head is same as screw diameter which is shown in column F.



Metric Bores and Keyways

Bore	Key	way	Shallow				Bore Sizes	Available			
Dia. (mm)	Width (mm)	Depth (mm)	Keyway Depth	3525	3535	4030	4040	4535	4545	5040	5050
35	10	3.3	—	•	•						
38	10	3.3	—	•	•						
40	12	3.3	—	•	•	•	•				
42	12	3.3	—	•	•	•	•				
45	14	3.8	—	•	•	•	•				
48	14	3.8	—	•	•	•	•				
50	14	3.8	—	•	•	•	•				
55	16	4.3	—	•	•	•	•	•	•		
60	18	4.4	—	•	•	•	•	•	•		
65	18	4.4	—	•	•	•	•	•	•		
70	20	4.9	—	•	•	•	•	•	•	•	•
75	20	4.9	—	•	•	•	•	•	•	•	•
80	22	5.4	—	•	•	•	•	•	•	•	•
85	22	5.4	—	•	•	•	•	•	•	•	•
90	25	5.4	—	•	•	•	•	•	•	•	•
95	25	5.4	—	•		•	•	•	•	•	•
100	28	6.4	4.4	•*		•	•	•	•	•	•
105	28	6.4	—			•		•	•	•	•
110	28	6.4	—			•		•	•	•	•
115	32	7.4	5.4			•*		•		•	•
120	32	7.4	—					•		•	•
125	32	7.4	—					•		•	•
130	32	7.4	—							•	
140	36	8.4	6.4							•*	


Items marked with""have a shallow keyway.

Inch Bores and Keyways

Bore	Key	way	Shallow				Bore Sizes	s Available			
Dia. (In.)	Width (In.)	Depth (In.)	Keyway Depth	3525	3535	4030	4040	4535	4545	5040	5050
1.500	0.375	0.11	—	•	•						
1.625	0.437	0.13	—	•	•						
1.750	0.437	0.13	—	•	•	•	•				
1.875	0.500	0.13	—	•	•	•	•				
2.000	0.500	0.13	—	•	•	•	•				
2.125	0.625	0.18	—	•	•	•	•	•	•		
2.250	0.625	0.18	—	•	•	•	•	•	•		
2.375	0.625	0.18	—	•	•	•	•	•	•		
2.500	0.625	0.18	—	•	•	•	•	•	•		
2.625	0.750	0.21	—	•	•	•	•	•	•	•	•
2.750	0.750	0.21	—	•	•	•	•	•	•	•	•
2.875	0.750	0.21	—	•	•	•	•	•	•	•	•
3.000	0.750	0.21	—	•	•	•	•	•	•	•	•
3.125	0.875	0.26	—	•	•	•	•	•	•	•	•
3.250	0.875	0.26	—	•	•	•	•	•	•	•	•
3.375	0.875	0.26	—	•	•	•	•	•	•	•	•
3.500	0.875	0.26	—	•	•	•	•	•	•	•	•
3.750	1.000	0.32	0.245	•*		•	•	•	•	•	•
4.000	1.000	0.32	0.155	•*		•	•	•	•	•	•
4.250	1.250	0.37	—			•		•	•	•	•
4.500	1.250	0.37	0.255			•*		•	•	•	•
4.750	1.250	0.37	—					•		•	•
5.000	1.250	0.37	0.258					•*		•	•

Items marked with" "have a shallow keyway.





No.6050 to 120100 Taper Bushings

								CØ						
Bushing Number	Bore	Weight (Kg)	Bushing Keyseat	Shaft Keyseat	A	В	Class 20 Gray Iron	Class 30 Gray Iron	Steel	D	E	F† (in)	L*	M **
6050	95 to 110 110 to 130 130 to 150	27 25 23	28 × 6.4 32 × 7.4 36 × 8.4	28 × 10 32 × 11 36 × 12	235.0	127.0	431.8	393.7	342.9	228.6	171.5	1 ¹ / ₄ × 3.11	41.3	111.1
7060	110 to 130 130 to 150 150 to 170	39 34 29	32 × 7.4 36 × 8.4 40 × 9.4	32 × 11 36 × 12 40 × 13	260.3	152.4	469.9	431.8	374.7	254.0	196.9	1 ¹ / ₄ × 3.11	41.3	111.1
F8065	130 to 139.7 150 to 165.1 170 to 190.5	54 45 38	36 × 8.4 40 × 9.4 45 × 10.4	36 × 12 40 × 13 45 × 15	285.7	165.1	482.6	444.5	393.7	279.4	222.3	1 ¹ / ₄ × 3.11	41.3	111.1
F10085	170 to 200 200 to 230 230 to 260	118 104 86	45 × 10.4 50 × 11.4 56 × 12.4	45 × 15 50 × 17 56 × 20	374.4	215.9	596.9	558.8	495.3	368.3	298.5	1 ¹ / ₂ × 4 ¹ / ₄	50.8	136.5
F120100	200 to 230 230 to 260 260 to 290	186 163 131	50 × 11.4 56 × 12.4 63 × 12.4	50 × 17 50 × 20 63 × 20	438.1	254.0	711.2	660.4	584.2	431.8	362.0	1 ¹ / ₂ × 4 ¹ / ₄	50.8	136.5

Bushings cannot be bored larger than largest bore listed

For detail dimensions required for machining hubs, consult Martin.

- For general reference. Severe conditions may require larger hub. Heavy well-located web may permit smaller hub. Hub diameter required depends on the particular application. Consult *Material* giving full information on the pmposed desIgn. Hub diameters shown are based on 1400, 2110 and 3500 Kg/Cm². minimum ultimate tensile strength respectivelyfor Class 20 gray iron, Class 30 gray iron and steel hubs.
- Three screws for 6050; four for 7060 to 10085; six for 120100. Use in postions shown or tightening bushing on shaft. In loosening bushing , remove screws and use all except one in the other holes. Bushing price includes screws.
- ★ Space required to tighten bushing. Also space required to loosen screws to permit removal of hub by puller.
- ★★ Space required to loosen bushing using screws as jackscrews no puller required.

F Not currently stocked - Available on order.




Taper Bushings

IMPORTANT : Follow all instructions in this manual carefully. This is necessary to insure satisfactory performance.



1008 to 3030






7060 to 10085

120100

To Install :

- 1. Clean shaft, bore, outside of bushing and bore of hub (taking bushing from hub if already assembled). Remove any oil, lacquer, or dirt. Place bushing in hub and match half holes to make complete holes (each complete hole will be threaded on one side only).
- 2. Oil thread and point of set screws or thread and under head of cap screws. Place screws loosely in holes that are threaded on hub side (shown thus \bigcirc in diagram).
- 3. Make sure bushing is free in hub. Slip assembly onto shaft and locate in position desired.
- 4. Tighten screws (see note*) alternately and evenly until all are pulled up very tightly. Use a piece of pipe on wrench to increase leverage. (See table for wrench torque on reverse side.)
- 5. Hammer against large end of bushing using hammer and block or sleeve to avoid damage. Screws can now be turned a little more using the specified wrench torque. Repeat this alternate hammering and screw retightening until the specified wrench torque no longer turns the screws after hammering.
- 6. After drive has been running under load for a short time stop and check tightness of screws. Fill other holes with grease to exclude dirt.



To Remove:

- 1. Remove all screws. Oil thread and point of set screws or thread and under head of cap screws.
- 2. Insert screws in holes that are threaded on bushing side (shown thus • in diagram). In sizes where washers are found under screw heads, be sure to use these washers. Note that one screw in each hub is left over and is not used in this loosening operation.
- 3. Tighten screws alternately until bushing is loosened in hub. If bushing does not loosen immediately, tap on hub.

Bush Size		1008	1108	1210	1610	1615	2012	2517	3020	3030	3525	3535	4030	4040	4535	4545	5040	5050
Screw Tightening Torque (Nm)		5.6	5.6	20	20	20	30	50	90	90	115	115	170	170	190	190	270	270
Screw	Qty	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3
	Size (BSW)	1/4	1/4	³ /8	³ /8	³ /8	⁷ / ₁₆	¹ / ₂	⁵ /8	⁵ /8	¹ / ₂	¹ / ₂	⁵ /8	⁵ /8	3/4	3/4	⁷ /8	⁷ /8
Details	Hex. Socket Size (mm)	3	3	5	5	5	6	6	8	8	10	10	12	12	14	14	14	14
Large End	Large End Dia. (mm)		38.0	47.5	57.0	57.0	70.0	85.5	108.0	108.0	127.0	127.0	146.0	146.0	162.0	162.0	177.5	177.5
Approx.	Approx. Mass (kg)		0.1	0.2	0.3	0.5	0.7	1.5	2.7	3.6	3.8	5.0	5.6	7.7	7.5	10.0	11.1	14.0

Recommended Wrench Torque

When ordering Bushings give: Number stamped on large end of bushing, bore, and quantity.

+ If two bushings are used in the same sheaves, pulley, or other unit member, tighten one bushing on shaft per steps 4 and 5 before starting to tighten screws in other bushing.

Taper Bushings Metric and Reborable



Stock Reborable Taper Bushings With No Keyways

Sinter	red Steel		Grey Iron	Ste	el *	Stainless	s Steel *
1008	⁹ / ₁₆			1008	1/ ₂	1008	1/2
1108	1/2			1108	1/2	1108	*
1210	⁹ / ₁₆			1210	1/2	1210	1/2
1215	1/2			1215	1/2	1215	*
1310	1/2			1310	*	1310	*
1610	¹ / ₂ 1 ⁵ / ₁₆			1610	1/ ₂	1610	1/ ₂
1615	¹ / ₂ 1 ⁵ / ₁₆			1615	1/2	1615	*
2012	1/2			2012	1/2	2012	1/2
2517	¹ / ₂ 1 ⁹ / ₁₆			2517	1/2	2517	1/2
		2525	2 ¹ / ₈	2525	*	2525	*
3020	$^{15}/_{16}$ 1 $^{11}/_{16}$	3020	$^{15}/_{16}$ 1 $^{7}/_{16}$ 2 $^{15}/_{16}$	3020	¹⁵ / ₁₆	3020	¹⁵ / ₁₆
		3030	$^{15}/_{16}$ 2 $^{7}/_{16}$ 2 $^{15}/_{16}$	3030	*	3030	*
		3535	$1^{3}/_{16}$ $2^{7}/_{16}$ $2^{15}/_{16}$	3535	*	3535	*
		4040	$1^{7}/_{16}$ $3^{7}/_{16}$ $3^{15}/_{16}$	4040	*	4040	*
		4545	$3^{15}/_{16}$ $4^{7}/_{16}$	4545	*	4545	*
		5050	2 ⁷ / ₁₆ 3 ¹⁵ / ₁₆				
		6050	3 ⁷ / ₁₆ 5 ⁷ / ₁₆				
		7060	3 ¹⁵ / ₁₆				
		8065	4 ⁷ / ₁₆				
		10085	7				
		120100	8				

 \bigstar Not currently stocked.Consult factory for availability and pricing. * Stock in U.S.A



Martin Taper Bushed Type W Weld-On Hubs are made of steel, drilled, tapped, and taper bored to receive Tapered Bushings. They are very useful for welding into fan rotors, pulleys, plate sprockets, impellers, agitators, and many other devices which must be firmly fastened to the shaft. Cases where the attached item is of small dimensions should be referred to *Martin*.

	Туре W														
Part Number	Bush No.	OD	В	C	L	E	F								
W12	1215	73.03	63.50	62.71	38.10	15.88	9.53								
W16	1615	82.55	73.03	72.24	38.10	15.88	9.53								
W20	2017	101.60	88.90	88.11	44.45	19.05	11.91								
W25	2517	127.00	111.13	110.34	44.45	19.05	12.70								
W30	3030	149.86	133.35	132.56	76.20	25.40	19.05								
W35	3535	184.15	158.75	157.96	88.90	31.75	25.40								
W40	4040	225.43	196.85	196.06	101.60	31.75	31.75								
W45	4545	254.00	222.25	221.46	114.30	38.10	38.10								


Taper Bushed Type W Weld-On Hubs

Taper Bushed Type WH Weld-On Hubs


			Type WH	I			
Part Number	Bush No.	OD	В	C	L	E	F
WH12	1210	70.00	65.00	64.50	25.00	9.00	10.00
WH16	1610	80.00	75.00	74.50	25.00	9.00	10.00
WH20	2012	95.00	90.00	89.50	32.00	12.00	12.00
WH25	2517	115.00	110.00	109.50	44.00	19.00	15.00
WH30	3020	145.00	140.00	139.50	50.00	20.00	15.00
WH35	3525	190.00	180.00	179.50	65.00	25.00	25.00
WH35-2	3535	190.00	180.00	179.50	89.00	25.00	25.00
WH40-1	4030	200.00	190.00	189.50	76.00	32.00	30.00
WH40-2	4040	200.00	190.00	189.50	101.00	32.00	30.00
WH45-1	4535	210.00	200.00	199.50	89.00	40.00	30.00
WH45-2	4545	210.00	200.00	199.50	114.00	40.00	30.00
WH50-1	5040	230.00	220.00	219.50	102.00	40.00	35.00
WH50-2	5050	230.00	220.00	219.50	127.00	40.00	35.00

Taper Bushed Type WM Weld-On Hubs


Туре WM									
Part Number	Bush No.	OD	В	C	L	E	F		
WM12	1210	70.00	60.00	58.00	25.00	9.00	10.00		
WM16-1	1610	83.00	70.00	68.00	25.00	9.00	10.00		
WM16-2	1615	83.00	70.00	68.00	38.00	16.00	11.00		
WM20	2012	95.00	90.00	88.00	32.00	12.00	12.00		
WM25	2517	127.00	110.00	108.00	44.00	19.00	13.00		
WM30-1	3020	152.00	130.00	125.00	50.00	20.00	15.00		
WM30-2	3030	152.00	130.00	125.00	76.00	25.00	19.00		
WM35	3535	184.00	155.00	151.00	89.00	32.00	25.00		
WM40	4040	225.00	195.00	187.00	102.00	32.00	32.00		
WM45	4545	254.00	220.00	213.00	114.00	38.00	38.00		
WM50	5050	276.00	242.00	228.00	127.00	38.00	38.00		



Type W



Type WH



Type WM

Taper Bushed Type BF Bolt-On Hubs

Туре ВF									
Part Number	Bush No.	OD	H	BC	L	E	J		
BF12	1210	120.00	80.00	100.00	25.00	6.50	6 × 6.6		
BF16	1610	130.00	90.00	110.00	25.00	6.50	6 × 6.6		
BF20	2012	145.00	100.00	125.00	32.00	8.50	6 × 9.0		
BF25	2517	185.00	130.00	155.00	44.00	11.50	6 × 11.0		
BF30	3020	220.00	165.00	190.00	50.00	11.50	6 × 13.0		


Taper Bushed Type SM Bolt-On Hubs

Type SM								
Part Number	Bush No.	OD	В	BC	L	E	н	J
SM12	1210	180.00	90.00	135.00	25.00	6.50	75.0	6 × 7.5
SM16	1615	200.00	110.00	150.00	38.00	7.50	85.0	6 × 7.5
SM20	2012	270.00	140.00	190.00	32.00	8.50	110.0	6 × 9.5
SM25	2517	340.00	170.00	240.00	45.00	9.50	125.0	8 × 11.5
SM30-1	3020	430.00	220.00	300.00	51.00	13.50	160.0	8 × 13.5
SM30-2	3020	485.00	250.00	340.00	51.00	13.50	160.0	8 × 13.5


Taper Bushed Adapters


Adapters								
Part Number Bush O		OD	L	Keyway				
	No.	00	L	Width	Depth			
1008BM	1008	45	22	5.0	2.5			
1008AM	1000	10		—	—			
1210BM	1210	60	25	6.0	3.0			
1210AM	1210			—	—			
1215BM	1215	60	38	6.0	3.0			
1215AM	1210	00	00	—	—			
1610BM	1610	70	25	10.0	4.0			
1610AM	1010	70	20	—	—			
1615BM	1615	70	38	10.0	4.0			
1615AM	1015	70	50	—	—			
2517BM	2517	105	45	16.0	4.0			
2517AM	2017	105	45	—	—			
3030BM	3030	130	76	20.0	5.0			
3030AM	3030	150	70	—	—			
3535BM	3535	160	89	22.0	5.0			
3535AM	0000	100	03	_	—			
4040BM	4040	185	102	24.0	5.0			
4040AM	0404	100	102		—			





Type BF







We also supply MST bushings, adaptors & Idler bushings, Call *Martin* , we will be happy to assist you!



MST[®] (*Martin* SPLIT TAPER)



$\text{MST}^{\texttt{B}}$ (Martin SPLIT TAPER) ADAPTERS



Notes





Notes

Notes





CHINA

Shanghai • Changzhou • Fuzhou Tel: +86 21 6708-4888 Fax: +86 21 6708-4889 IntlSales@martinsprocket.com

USA

Corporate Offices Sales & Manufacturing Arlington, TX Tel: 817-258-3000 Fax: 817-258-3333 **Regional Manufacturing Plants** Albemarle, NC • Atlanta, GA • Burleson, TX • Danielsville, PA • Ft. Worth, TX • Montpelier, OH • Sacramento, CA **Branch Manufacturing Plants** Boston, MA • Charlotte, NC • Chicago, IL • Denver, CO • Houston, TX • Kansas City, MO • Los Angeles, CA • Minneapolis, MN •Nashville, TN • Pittsburgh,PA • Portland, OR • Tampa, FL **Manufacturing Only** Abilene, TX • Clarksville, TX • Dallas, TX • Mansfield, TX • Paragould, AR

CANADA

Cambridge, Ontario Edmonton, Alberta Mississauga, Ontario

MEXICO Guadalajara, JAL Monterrey, N.L. Toluca, MEX

BRAZIL São Paulo, SP

UNITED KINGDOM

Warwickshire, UK Tel: +44 (0) 1926 962161 EMEASales@martinsprocket.com

Distributor authorized by Martin

www.martinsprocket.com